


Hinge Adjustment Guide

All of our hinges are 6-way adjustable that allows fine tuning in 3 dimensions:


- 1 **Up and down** - for door alignment
- 2 **In and out** - adjusts space between door and cabinet
- 3 **Side to side** - adjusts gap between two doors.



Framed Cabinet Hinges

Center Screw:

Loosen screw to move door up and down



Back Screw:


Turn screw to move the door in and out

Front Screw:

Turn screw to move the door side to side

Hinge Plate Screws:

Loosen screw to move door up and down



Front Screw:

Turn screw to move the door side to side

Back Screw:

Turn screw to move the door in and out